

MITSUBISHI

FRONT WHEEL DRIVE AUTOMATIC TRANSMISSION (E-W)

WORKSHOP MANUAL

FOREWORD

This Workshop Manual contains procedures for removal, disassembly, inspection, adjustment, reassembly and installation, etc. for service mechanics.

All information, illustrations and product descriptions contained in this manual are current as at the time of publication. We, however, reserve the right to make changes at any time without prior notice or obligation.

Automatic Transmisson **23A**
F4A4, F4A5

FILING INSTRUCTION

Please keep these manual pages in the binder No. BN940001.

File these pages according to the signs "Added", "Revised" and "Deleted" on the "List of effective pages" which are interpreted below.

Added:

File the pages with this sign additionally in your manual.

Revised, Deleted:

Replace the existing pages with the corresponding pages with this sign.

Missing sheets will be supplied upon request.

 MITSUBISHI MOTORS CORPORATION

INTRODUCTION

EXPLANATION OF MANUAL CONTENTS

Maintenance and Servicing Procedures

- (1) A diagram of the component parts is provided near the front of each section in order to give the reader a better understanding of the installed condition of component parts.
- (2) The numbers provided within the diagram indicate the sequence for maintenance and servicing procedures.
N : Indicates a non-reusable part.
The tightening torque is provided where applicable.

- **Removal steps:**
The part designation number corresponds to the number in the illustration to indicate removal steps.
- **Disassembly steps:**
The part designation number corresponds to the number in the illustration to indicate disassembly steps.
- **Installation steps:**
Specified in case installation is impossible in reverse order of removal steps. Omitted if installation is possible in reverse order of removal steps.
- **Reassembly steps:**
Specified in case reassembly is impossible in reverse order of disassembly steps. Omitted if reassembly is possible in reverse order of disassembly steps.





Classification of Major Maintenance/Service Points

When there are major points relative to maintenance and servicing procedures (such as essential maintenance and service points, maintenance and service standard values, information regarding the use of special tools, etc.), these are arranged together as major maintenance and service points and explained in detail.

- ◀A▶** : Indicates that there are essential points for removal or disassembly.
▶A◀ : Indicates that there are essential points for installation or reassembly.

Symbols for Lubrication, Sealants and Adhesives

Information concerning the locations for lubrication and for application of sealants and adhesives is provided, by using symbols, in the diagram of component parts, or on the page following the component parts page, and explained.

-  : Grease
(multipurpose grease unless there is a brand or type specified)
-  : Sealant or adhesive
-  : Brake fluid, automatic transmission fluid or air conditioner compressor oil
-  : Engine oil or gear oil

INTRODUCTION

Indicates the group title.

Indicates the section title.

Indicates the group number.

Indicates the section number.


Indicates the page number.

AUTOMATIC TRANSMISSION (E-W) - Transfer Drive Gear 23A-11-1

11. TRANSFER DRIVE GEAR DISASSEMBLY AND REASSEMBLY

23302240018

Lubricate all internal parts with automatic transmission fluid during reassembly.



Denotes non-reusable part.

Denotes tightening torque.

This number corresponds to the number appearing in "Removal steps", "Disassembly steps", "Installation steps" or "Reassembly steps".


Disassembly steps

1. Lock nut
2. Transfer drive gear bearing
3. Transfer drive gear

DISASSEMBLY SERVICE POINTS

LOCK NUT REMOVAL

- (1) Pull up the turning stopper of the lock nut.



© Mitsubishi Motors Corporation May 1998

PWE8014

Operating procedures, cautions, etc. on removal, installation, disassembly and reassembly are described.

Issue date

Publication number-Revision code

LIST OF EFFECTIVE PAGES

| Page | Revision Code | Date | Remarks | Page | Revision Code | Date | Remarks |
|-----------------------|---------------|-----------|---------|-------------------------|---------------|-----------|---------|
| 23A-0-1 | E | Aug. 1999 | Revised | 23A-3-17 to 23A-3-19 | E | Aug. 1999 | Revised |
| 23A-0-2 | | May 1995 | | 23A-3-19a and 23A-3-19b | E | Aug. 1999 | Revised |
| 23A-0-3 | A | Nov. 1995 | | 23A-3-19c and 23A-3-19d | E | Aug. 1999 | Added |
| 23A-0-4 to 23A-0-6 | E | Aug. 1999 | Revised | 23A-3-20 and 23A-3-21 | E | Aug. 1999 | Revised |
| 23A-0-6a to 23A-0-6d | E | Aug. 1999 | Added | 23A-3-22 | B | Feb. 1997 | |
| 23A-0-7 and 23A-0-8 | B | Feb. 1997 | | 23A-3-22a and 23A-3-22b | B | Feb. 1997 | |
| 23A-1-1 | D | Jun. 1998 | | 23A-3-23 | E | Aug. 1999 | Revised |
| 23A-1-2 | E | Aug. 1999 | Revised | 23A-3-24 and 23A-3-25 | | May 1995 | |
| 23A-1-2a and 23A-1-2b | E | Aug. 1999 | Revised | 23A-3-26 and 23A-3-27 | E | Aug. 1999 | Revised |
| 23A-1-3 | A | Nov. 1995 | | 23A-3-27a and 23A-3-27b | E | Aug. 1999 | Added |
| 23A-1-4 | B | Feb. 1997 | | 23A-3-28 | E | Aug. 1999 | Revised |
| 23A-1-5 | E | Aug. 1999 | Revised | 23A-3-29 to 23A-3-32 | B | Feb. 1997 | |
| 23A-1-6 and 23A-1-7 | B | Feb. 1997 | | 23A-3-33 | E | Aug. 1999 | Revised |
| 23A-1-8 and 23A-1-9 | E | Aug. 1999 | Revised | 23A-3-34 | B | Feb. 1997 | |
| 23A-1-10 | B | Feb. 1997 | | 23A-4-1 | E | Aug. 1999 | Revised |
| 23A-2-1 | B | Feb. 1997 | | 23A-4-2 | | | Deleted |
| 23A-2-2 to 23A-2-4 | E | Aug. 1999 | Revised | 23A-5-1 and 23A-5-2 | B | Feb. 1997 | |
| 23A-2-5 | E | Aug. 1999 | Added | 23A-5-3 | E | Aug. 1999 | Revised |
| 23A-3-1 | E | Aug. 1999 | Revised | 23A-6-1 to 23A-6-4 | E | Aug. 1999 | Revised |
| 23A-3-2 and 23A-3-3 | B | Feb. 1997 | | 23A-7-1 | E | Aug. 1999 | Revised |
| 23A-3-4 | E | Aug. 1999 | Revised | 23A-7a-1 and 23A-7a-2 | E | Aug. 1999 | Added |
| 23A-3-5 | B | Feb. 1997 | | 23A-8-1 | | May 1995 | |
| 23A-3-5a to 23A-3-5f | E | Aug. 1999 | Revised | 23A-9-1 | | May 1995 | |
| 23A-3-5g to 23A-3-5n | E | Aug. 1999 | Added | 23A-10-1 | | May 1995 | |
| 23A-3-6 | | May 1995 | | 23A-10-2 | B | Feb. 1997 | |
| 23A-3-7 | E | Aug. 1999 | Revised | 23A-11-1 and 23A-11-2 | E | Aug. 1999 | Revised |
| 23A-3-8 to 23A-3-12 | B | Feb. 1997 | | 23A-12-1 | B | Feb. 1997 | |
| 23A-3-13 | E | Aug. 1999 | Revised | 23A-12-2 | | May 1995 | |
| 23A-3-14 | B | Feb. 1997 | | 23A-12-3 | E | Aug. 1999 | Revised |
| 23A-3-15 and 23A-3-16 | E | Aug. 1999 | Revised | 23A-13-1 to 23A-13-4 | | May 1995 | |
| 23A-3-16a | E | Aug. 1999 | Revised | 23A-14-1 | E | Aug. 1999 | Revised |
| 23A-3-16b | B | Feb. 1997 | | 23A-15-1 and 23A-15-2 | | May 1995 | |

Missing sheets will be supplied upon request.

AUTOMATIC TRANSMISSION F4A41, F4A42, F4A51

CONTENTS

| | |
|--|-----------------|
| GENERAL INFORMATION | 23A-0-3 |
| 1. SPECIFICATIONS | 23A-1-1 |
| TRANSMISSION MODEL TABLE | 23A-1-1 |
| GENERAL SPECIFICATIONS | 23A-1-2a |
| SERVICE SPECIFICATIONS | 23A-1-2b |
| VALVE BODY SPRING IDENTIFICATION TABLE | 23A-1-3 |
| SNAP RING, SPACER, THRUST WASHER, THRUST RACE AND PRESSURE PLATE FOR ADJUSTMENT | 23A-1-4 |
| TORQUE SPECIFICATIONS | 23A-1-9 |
| SEALANTS | 23A-1-10 |
| 2. SPECIAL TOOLS | 23A-2-1 |
| 3. TRANSMISSION | 23A-3-1 |
| 4. OIL PUMP | 23A-4-1 |
| 5. UNDERDRIVE CLUTCH AND INPUT SHAFT | 23A-5-1 |
| 6. REVERSE CLUTCH AND OVERDRIVE CLUTCH | 23A-6-1 |
| 7. OVERDRIVE PLANETARY CARRIER <F4A41, F4A42 without ONE-WAY CLUTCH> | 23A-7-1 |
| 7a. PLANETARY CARRIER ASSEMBLY <F4A42 with ONE-WAY CLUTCH, F4A51> | 23A-7a-1 |
| 8. LOW-REVERSE BRAKE | 23A-8-1 |
| 9. SECOND BRAKE | 23A-9-1 |
| 10. OUTPUT SHAFT | 23A-10-1 |
| 11. TRANSFER DRIVE GEAR <F4A41 up to Dec. 1997, F4A42 up to Dec. 1997> | 23A-11-1 |
| 12. DIFFERENTIAL | 23A-12-1 |
| 13. VALVE BODY | 23A-13-1 |
| 14. SPEEDOMETER GEAR | 23A-14-1 |
| 15. DRIVE SHAFT OIL SEAL | 23A-15-1 |


23A-0-2

NOTES

GENERAL INFORMATION

- (1) The combination of highest-precision electronic and mechanical technology heralds a new era in automatic transmission performance.
- (2) The gear shifting clutches use a hydraulic balancing mechanism to enable gear shifting at extra-high engine speeds.
- (3) The number of shafts has been decreased to two, increased use has been made of metal plates and the one-way clutch has been abolished, which all contribute to reduce the weight.
- (4) Increased meshing ratios and improved rigidity of the gear supports and casing result in less noise.
- (5) In addition, adoption of a newly-developed automatic transmission fluid (ATF) and an external oil filter eliminates the need to periodically replace the fluid.
- (6) The number of oil cooler feed tubes is increased to two.

3-DIMENSIONAL CROSS-SECTION




TFA1502

23A-0-4 AUTOMATIC TRANSMISSION (E-W) – General Information


SECTIONAL VIEW

<F4A41 up to Dec. 1997>



TFA1548


<F4A41 from Jan. 1998>



TFA2252


23A-0-6 AUTOMATIC TRANSMISSION (E-W) – General Information

<F4A42-1 up to Dec. 1997>



TFA1503


<F4A42-1 from Jan. 1998>



TFA2253


23A-0-6b AUTOMATIC TRANSMISSION (E-W) – General Information

<F4A42-2 without one-way clutch>



TFA1504


<F4A42-2 with one-way clutch>



TFA2254


Intentionally blank

<F4A51>



TFA1995

HYDRAULIC CIRCUIT



TFA1598

- | | |
|--|---|
| 1. Reverse clutch | 18. Overdrive pressure control valve |
| 2. Low-reverse brake | 19. Damper clutch control solenoid valve |
| 3. Second brake | 20. Low-reverse solenoid valve |
| 4. Underdrive clutch | 21. Second solenoid valve |
| 5. Overdrive clutch | 22. Underdrive solenoid valve |
| 6. Low-reverse accumulator | 23. Overdrive solenoid valve |
| 7. Second accumulator | 24. Torque converter pressure control valve |
| 8. Underdrive accumulator | 25. Regulator valve |
| 9. Overdrive accumulator | 26. Manual valve |
| 10. Damper clutch | 27. Oil filter |
| 11. Fail-safe valve A | 28. Oil filter |
| 12. Fail-safe valve B | 29. Oil pan |
| 13. Damper clutch control valve | 30. Oil pump |
| 14. Switching valve | 31. Relief valve |
| 15. Low-reverse pressure control valve | 32. Oil strainer |
| 16. Second pressure control valve | |
| 17. Underdrive pressure control valve | |

1. SPECIFICATIONS

TRANSMISSION MODEL TABLE

MODEL 1996

| Transmission model | | Speedometer gear ratio | Final gear ratio | Vehicle model | Engine model |
|--------------------|--------------|------------------------|------------------|---------------|--------------|
| EUR | F4A41-1-MRA | 31/36 | 4.042 | DA1A | 4G92 |
| | F4A41-1-M8A1 | 31/36 | 4.042 | CJ4A, CK4A | 4G92 |
| | F4A41-1-M8A2 | 31/36 | 4.042 | CJ1A | 4G13 |
| | F4A42-1-MRA | 31/36 | 4.042 | DA2A | 4G93 |
| EXP | F4A41-1-M8A | 31/36 | 4.042 | CJ2A | 4G15 |
| | F4A41-1-M8A1 | 31/36 | 4.042 | CJ4A | 4G92 |
| | F4A41-1-M8A4 | 31/36 | 4.042 | CK2A | 4G15 |
| | F4A41-1-M8A5 | 31/36 | 4.042 | CK1A | 4G13 |

MODEL 1997

| Transmission model | | Speedometer gear ratio | Final gear ratio | Vehicle model | Engine model |
|--------------------|--------------|------------------------|------------------|---------------|--------------|
| EUR | F4A42-1-M7A | 30/36 | 4.042 | EA2A, EA2W | 4G63 |
| | F4A42-2-E6A | 29/36 | 3.770 | EA5A, EA5W | 6A13 |
| EXP | F4A42-1-M6A | 29/36 | 4.042 | EA1A | 4G93 |
| | F4A42-1-M6A2 | 29/36 | 4.042 | EA2A | 4G63 |
| | F4A42-1-M7A | 30/36 | 4.042 | EA2A | 4G63 |
| | F4A42-1-U6A1 | 29/36 | 4.407 | EA4A | 6A12 |
| | F4A42-2-E6A | 29/36 | 3.770 | EA5A | 6A13 |
| | F4A51-2-E5B | 28/36 | 3.735 | F36A | 6G72 |

MODEL 1998

| Transmission model | | Speedometer gear ratio | Final gear ratio | Vehicle model | Engine model |
|--------------------|--------------|------------------------|------------------|---------------|--------------|
| EUR | F4A41-1-M8A1 | 31/36 | 4.042 | CJ4A | 4G92 |
| | F4A41-1-M8A5 | 31/36 | 4.042 | CJ1A, CK1A | 4G13 |
| | F4A41-1-M8A6 | 31/36 | 4.042 | DA1A | 4G92 |
| | F4A42-1-E8A | 31/36 | 3.770 | DA2A | 4G93-GDI |
| | F4A42-1-M7A | 30/36 | 4.042 | EA2A, EA2W | 4G63 |
| | F4A42-1-M8A3 | 31/36 | 4.042 | DA2A | 4G93 |
| | F4A42-2-E6A | 29/36 | 3.770 | EA5A, EA5W | 6A13 |

23A-1-2

AUTOMATIC TRANSMISSION (E-W) – Specifications

| Transmission model | | Speedometer gear ratio | Final gear ratio | Vehicle model | Engine model |
|--------------------|--------------|------------------------|------------------|---------------|--------------|
| EXP | F4A41-1-M8A1 | 31/36 | 4.042 | CJ4A, CK4A | 4G92 |
| | F4A41-1-M8A4 | 31/36 | 4.042 | CJ2A, CK2A | 4G15 |
| | F4A41-1-M8A5 | 31/36 | 4.042 | CK1A | 4G13 |
| | F4A42-1-M6A | 29/36 | 4.042 | EA1A | 4G93 |
| | F4A42-1-M6A2 | 29/36 | 4.042 | EA2A | 4G63 |
| | F4A42-2-E6A | 29/36 | 3.770 | EA5A | 6A13 |
| | F4A51-2-E5B | 28/36 | 3.735 | F36A | 6G72 |

MODEL 1999

| Transmission model | | Speedometer gear ratio | Final gear ratio | Vehicle model | Engine model |
|--------------------|--------------|------------------------|------------------|---------------|--------------|
| EUR | F4A42-1-U5A1 | 28/36 | 4.407 | N61W | 4G93-GDI |
| | F4A42-2-E6B | 29/36 | 3.770 | EA3A, EA3W | 4G64-GDI |
| | F4A42-2-E6B1 | 29/36 | 3.770 | EA5A, EA5W | 6A13 |
| | F4A42-2-M5B1 | 28/36 | 4.042 | N84W | 4G64-GDI |
| EXP | F4A42-2-E6B1 | 29/36 | 3.770 | EA5A | 6A13 |
| | F4A42-2-M5B | 28/36 | 4.042 | N84W | 4G64-S4 |

MODEL 2000

| Transmission model | | Speedometer gear ratio | Final gear ratio | Vehicle model | Engine model |
|--------------------|--------------|------------------------|------------------|---------------|--------------|
| EUR | F4A41-1-M8A1 | 31/36 | 4.042 | CJ4A | 4G92 |
| | F4A41-1-M8A5 | 31/36 | 4.042 | CJ1A | 4G13 |
| | F4A41-1-U8A2 | 31/36 | 4.407 | DA1A | 4G92 |
| | F4A42-1-M7A1 | 30/36 | 4.042 | DA2A | 4G93 |
| | F4A42-1-U5A2 | 28/36 | 4.407 | N63W | 4G63 |
| | F4A42-2-M5B1 | 28/36 | 4.042 | N64W, M84W | 4G64 |
| EXP | F4A41-1-M8A1 | 31/36 | 4.042 | CJ4A, CK4A | 4G92 |
| | F4A41-1-M8A4 | 31/36 | 4.042 | CJ2A, CK2A | 4G15 |
| | F4A41-1-M8A5 | 31/36 | 4.042 | CJ1A, CK1A | 4G13 |
| | F4A42-1-M6A | 29/36 | 4.042 | EA1A | 4G93 |
| | F4A42-1-M6A2 | 29/36 | 4.042 | EA2A | 4G63 |
| | F4A42-2-E6B1 | 29/36 | 3.770 | EA5A | 6A13 |
| | F4A42-2-M5B | 28/36 | 4.042 | N84W | 4G64 |
| AUS | F4A42-2-M5B | 28/36 | 4.042 | N84W | 4G64 |

GENERAL SPECIFICATIONS

| Items | | F4A41 | F4A42-1 | F4A42-2 | F4A51 |
|----------------------------------|---------|--|--|--|--|
| Torque converter type | | 3-element, 1-stage, 2-phase type | 3-element, 1-stage, 2-phase type | 3-element, 1-stage, 2-phase type | 3-element, 1-stage, 2-phase type |
| Transmission type | | 4-speed forward, 1-speed reverse | 4-speed forward, 1-speed reverse | 4-speed forward, 1-speed reverse | 4-speed forward, 1-speed reverse |
| Gear ratio | 1st | 2.842 | 2.842 | 2.842 | 2.842 |
| | 2nd | 1.529 | 1.529 | 1.529 | 1.495 |
| | 3rd | 1.000 | 1.000 | 1.000 | 1.000 |
| | 4th | 0.712 | 0.712 | 0.712 | 0.731 |
| | Reverse | 2.480 | 2.480 | 2.480 | 2.720 |
| Number of underdrive clutch disc | | 3 | 4 | 4 | 4 |
| Number of overdrive clutch disc | | 3 | 4 | 4 | 4 |
| Number of reverse clutch disc | | 2 | 2 | 2 | 2 |
| Number of low-reverse brake disc | | 4 | 5 | 6 | 6 |
| Number of second brake disc | | 2 | 3 | 3 | 4 |

23A-1-2b AUTOMATIC TRANSMISSION (E-W) – Specifications

SERVICE SPECIFICATIONS

| Items | | Standard value |
|---|--------------|----------------|
| Output shaft preload mm | | 0.01 – 0.09 |
| Brake reaction plate end play mm | | 0 – 0.16 |
| Low-reverse brake end play mm | F4A41 | 1.05 – 1.51 |
| | F4A42 | 1.35 – 1.81 |
| | F4A51 | 1.65 – 2.11 |
| Second brake end play mm | F4A41 | 0.49 – 0.95 |
| | F4A42 | 0.79 – 1.25 |
| | F4A51 | 1.09 – 1.55 |
| Underdrive sun gear end play mm | | 0.25 – 0.45 |
| Input shaft end play mm | | 0.70 – 1.45 |
| Differential case end play mm | F4A41 | 0.045 – 0.165 |
| Differential case preload mm | F4A42, F4A51 | 0.045 – 0.105 |
| Underdrive clutch end play mm | F4A41 | 1.2 – 1.4 |
| | F4A42, F4A51 | 1.6 – 1.8 |
| Reverse and overdrive clutch return spring retainer end play mm | | 0 – 0.09 |
| Overdrive clutch end play mm | F4A41 | 1.2 – 1.4 |
| | F4A42, F4A51 | 1.6 – 1.8 |
| Reverse clutch end play mm | | 1.5 – 1.7 |
| Backlash between differential side gear and pinion mm | | 0.025 – 0.150 |

VALVE BODY SPRING IDENTIFICATION TABLE

mm

| Spring | Wire diameter | Outside diameter | Free length | Number of loops |
|---|---------------|------------------|-------------|-----------------|
| Regulator valve spring | 1.8 | 15.7 | 86.7 | 24 |
| Underdrive pressure control valve spring | 0.7 | 7.6 | 37.7 | 25 |
| Overdrive pressure control valve spring | 0.7 | 7.6 | 37.7 | 25 |
| Low-reverse pressure control valve spring | 0.7 | 7.6 | 37.7 | 25 |
| Second pressure control valve spring | 0.7 | 7.6 | 37.7 | 25 |
| Torque converter spring | 1.6 | 11.2 | 34.4 | 12.5 |
| Damper clutch control valve spring | 0.7 | 5.9 | 28.1 | 19 |
| Fail-safe valve A spring | 0.7 | 8.9 | 21.9 | 9.5 |
| Damping valve spring | 1.0 | 7.7 | 35.8 | 17 |
| Line relief valve spring | 1.0 | 7.0 | 17.3 | 10 |
| Orifice check ball spring | 0.5 | 4.5 | 17.2 | 15 |

SNAP RING, SPACER, THRUST WASHER, THRUST RACE AND PRESSURE PLATE FOR ADJUSTMENT

| Part name | Thickness mm | Identification symbol | Part No. |
|---|--------------|-----------------------|----------|
| Thrust washer (For adjustment of input shaft end play) | 1.8 | 18 | MD754509 |
| | 2.0 | 20 | MD754508 |
| | 2.2 | 22 | MD754507 |
| | 2.4 | 24 | MD753793 |
| | 2.6 | 26 | MD753794 |
| | 2.8 | 28 | MD753795 |
| Snap ring: F4A41, F4A42 (For adjustment of underdrive clutch and overdrive clutch end plays) | 1.6 | None | MD759666 |
| | 1.7 | Blue | MD759667 |
| | 1.8 | Brown | MD759668 |
| | 1.9 | None | MD752124 |
| | 2.0 | Blue | MD752125 |
| | 2.1 | Brown | MD752126 |
| | 2.2 | None | MD752127 |
| | 2.3 | Blue | MD752128 |
| | 2.4 | Brown | MD752129 |
| | 2.5 | None | MD752130 |
| | 2.6 | Blue | MD752131 |
| | 2.7 | Brown | MD752132 |
| | 2.8 | None | MD752133 |
| | 2.9 | Blue | MD752134 |
| 3.0 | Brown | MD754680 | |
| Snap ring: F4A51 (For adjustment of underdrive clutch and overdrive clutch end plays) | 1.6 | Brown | MD759960 |
| | 1.7 | None | MD759961 |
| | 1.8 | Blue | MD759962 |
| | 1.9 | Brown | MD759963 |
| | 2.0 | None | MD750841 |
| | 2.1 | Blue | MD750842 |
| | 2.2 | Brown | MD750843 |
| | 2.3 | None | MD750844 |
| | 2.4 | Blue | MD750845 |
| | 2.5 | Brown | MD750846 |
| | 2.6 | None | MD750847 |
| | 2.7 | Blue | MD750848 |
| | 2.8 | Brown | MD750849 |
| | 2.9 | None | MD750850 |
| 3.0 | Blue | MD750851 | |
| Snap ring: F4A41, F4A42 (For adjustment of low-reverse brake and second brake reaction plates end plays) | 2.2 | Blue | MD754786 |
| | 2.3 | Brown | MD754787 |
| | 2.4 | None | MD758240 |
| | 2.5 | Blue | MD758241 |

| Part name | Thickness mm | Identification symbol | Part No. |
|--|--------------|-----------------------|----------|
| Snap ring: F4A51 (For adjustment of low-reverse brake and second brake reaction plates end plays) | 2.2 | None | MD756784 |
| | 2.3 | Blue | MD756785 |
| | 2.4 | Brown | MD758552 |
| | 2.5 | None | MD758553 |
| Pressure plate: F4A41, F4A42 (For adjustment of low-reverse brake and second brake end play) | 1.6 | L | MD759567 |
| | 1.8 | 1 | MD759414 |
| | 2.0 | 0 | MD759415 |
| | 2.2 | 2 | MD759416 |
| | 2.4 | 4 | MD759417 |
| | 2.6 | 6 | MD759418 |
| | 2.8 | 8 | MD759419 |
| | 3.0 | D | MD759420 |
| Pressure plate: F4A51 (For adjustment of low-reverse brake and second brake end play) | 1.6 | F | MD759568 |
| | 1.8 | E | MD759425 |
| | 2.0 | D | MD759426 |
| | 2.2 | C | MD759427 |
| | 2.4 | B | MD759428 |
| | 2.6 | A | MD759429 |
| | 2.8 | 0 | MD759430 |
| | 3.0 | 1 | MD759431 |
| Snap ring: F4A41, F4A42 (For adjustment of reverse clutch end play) | 1.6 | None | MD761085 |
| | 1.7 | Blue | MD761086 |
| | 1.8 | Brown | MD761087 |
| | 1.9 | None | MD752137 |
| | 2.0 | Blue | MD752138 |
| | 2.1 | Brown | MD752139 |
| | 2.2 | None | MD752140 |
| | 2.3 | Blue | MD752141 |
| | 2.4 | Brown | MD752142 |
| | 2.5 | None | MD752143 |
| | 2.6 | Blue | MD752144 |
| | 2.7 | Brown | MD752145 |
| 2.8 | None | MD752146 | |

23A-1-6**AUTOMATIC TRANSMISSION (E-W) – Specifications**

| Part name | Thickness mm | Identification symbol | Part No. |
|--|--------------|-----------------------|----------|
| Snap ring: F4A51 (For adjustment of reverse clutch end play) | 1.6 | None | MD761008 |
| | 1.7 | Blue | MD761089 |
| | 1.8 | Brown | MD761090 |
| | 1.9 | None | MD758947 |
| | 2.0 | Blue | MD756690 |
| | 2.1 | Brown | MD756691 |
| | 2.2 | None | MD756692 |
| | 2.3 | Blue | MD756693 |
| | 2.4 | Brown | MD756694 |
| | 2.5 | None | MD756695 |
| | 2.6 | Blue | MD756696 |
| | 2.7 | Brown | MD756697 |
| | 2.8 | None | MD756698 |
| Snap ring (For adjustment of reverse clutch and overdrive clutch spring retainers end plays) | 1.48 | Brown | MD755600 |
| | 1.53 | None | MD755601 |
| | 1.58 | Blue | MD755602 |
| | 1.63 | Brown | MD755603 |
| Thrust race (For adjustment of underdrive sun gear end play) | 1.6 | – | MD707267 |
| | 1.7 | – | MD759681 |
| | 1.8 | – | MD723064 |
| | 1.9 | – | MD754794 |
| | 2.0 | – | MD707268 |
| | 2.1 | – | MD754795 |
| | 2.2 | – | MD723065 |
| | 2.3 | – | MD754796 |
| | 2.4 | – | MD724358 |
| | 2.5 | – | MD754797 |
| 2.6 | – | MD754798 | |

| Part name | Thickness mm | Identification symbol | Part No. |
|--|---|-----------------------|----------|
| Spacer (For adjustment of output shaft preload) | 1.88 | 88 | MD756579 |
| | 1.92 | 92 | MD756580 |
| | 1.96 | 96 | MD756581 |
| | 2.00 | 00 | MD756582 |
| | 2.04 | 04 | MD756583 |
| | 2.08 | 08 | MD756584 |
| | 2.12 | 12 | MD756585 |
| | 2.16 | 16 | MD756586 |
| | 2.20 | 20 | MD756587 |
| | 2.24 | 24 | MD756588 |
| | 2.28 | 28 | MD756589 |
| | 2.32 | 32 | MD756590 |
| | 2.36 | 36 | MD756591 |
| | 2.40 | 40 | MD756592 |
| | 2.44 | 44 | MD756593 |
| | 2.48 | 48 | MD756594 |
| | 2.52 | 52 | MD756595 |
| | 2.56 | 56 | MD756596 |
| | 2.60 | 60 | MD756597 |
| | Spacer: F4A41 (For adjustment of differential case end play) | 2.64 | 64 |
| 2.68 | | 68 | MD756599 |
| 2.72 | | 72 | MD760685 |
| 2.76 | | 76 | MD760686 |
| 1.28 | | N | MD710458 |
| 1.37 | | P | MD710460 |
| 1.46 | | R | MD710462 |
| 1.55 | T | MD710464 | |
| 1.64 | V | MD710466 | |
| 1.73 | X | MD710468 | |
| 1.82 | Z | MD710470 | |

| Part name | Thickness mm | Identification symbol | Part No. |
|--|--------------|-----------------------|----------|
| Spacer: F4A42, F4A51 (For adjustment of differential case preload) | 0.71 | 71 | MD754475 |
| | 0.74 | 74 | MD727660 |
| | 0.77 | 77 | MD754476 |
| | 0.80 | 80 | MD727661 |
| | 0.83 | 83 | MD720937 |
| | 0.86 | 86 | MD720938 |
| | 0.89 | 89 | MD720939 |
| | 0.92 | 92 | MD720940 |
| | 0.95 | 95 | MD720941 |
| | 0.98 | 98 | MD720942 |
| | 1.01 | 01 | MD720943 |
| | 1.04 | 04 | MD720944 |
| | 1.07 | 07 | MD720945 |
| | 1.10 | J | MD710454 |
| | 1.13 | D | MD700270 |
| | 1.16 | K | MD710455 |
| | 1.19 | L | MD710456 |
| | 1.22 | G | MD700271 |
| | 1.25 | M | MD710457 |
| | 1.28 | N | MD710458 |
| 1.31 | E | MD706574 | |
| 1.34 | O | MD710459 | |
| 1.37 | P | MD710460 | |
| Spacer (For adjustment of backlash between differential side gear and pinion) | 0.75 – 0.82 | – | MD722986 |
| | 0.83 – 0.92 | – | MD722985 |
| | 0.93 – 1.00 | – | MD722984 |
| | 1.01 – 1.08 | – | MD722982 |
| | 1.09 – 1.16 | – | MD722983 |

TORQUE SPECIFICATIONS










| Items | Nm | |
|--|---|-----|
| Transmission | Roll stopper bracket | 70 |
| | Wiring harness bracket | 23 |
| | Control cable bracket | 23 |
| | Eye bolt | 31 |
| | Oil cooler feed tube (to transmission case) | 10 |
| | Oil cooler feed tube (to roll stopper bracket) | 11 |
| | Oil filter | 12 |
| | Input shaft speed sensor | 11 |
| | Output shaft speed sensor | 11 |
| | Manual control lever | 22 |
| | Inhibitor switch | 11 |
| | Speedometer gear | 5 |
| | Valve body cover | 11 |
| | Valve body mounting bolt | 11 |
| | Fluid temperature sensor | 11 |
| | Manual control shaft detent | 6 |
| | Rear cover | 23 |
| | Torque converter housing | 48 |
| | Oil pump | 23 |
| | Transfer drive gear bearing <F4A41 up to Dec. 1997, F4A42 up to Dec. 1997> | 19 |
| | Transfer drive gear bearing <F4A41 from Jan. 1998, F4A42-1 from Jan. 1998, F4A42-2 with one-way clutch, F4A51> | 34 |
| Output shaft lock nut | 170 | |
| Output shaft bearing retainer <F4A41, F4A42> | 23 | |
| Output shaft bearing retainer <F4A51> | 54 | |
| Components | Transfer drive gear lock nut <F4A41 up to Dec. 1997, F4A42 up to Dec. 1997> | 195 |
| | Differential drive gear | 135 |
| | Valve body | 11 |
| | Solenoid valve support | 6 |
| | Plate | 6 |










23A-1-10 AUTOMATIC TRANSMISSION (E-W) – Specifications










SEALANTS

| Items | Specified sealant |
|--------------------------|--|
| Rear cover | Mitsubishi genuine sealant Part No. MD974421 or equivalent |
| Torque converter housing | Mitsubishi genuine sealant Part No. MD974421 or equivalent |
| Valve body cover | Mitsubishi genuine sealant Part No. MD974421 or equivalent |




2. SPECIAL TOOLS

| Tool | Number | Name | Use |
|---|----------|----------------------|--|
|  | MB990607 | Torque wrench socket | Removal and installation of output shaft lock nut |
|  | MB990928 | Installer adapter | Removal of transfer drive gear bearing <F4A41, F4A42> |
|  | MB990930 | Installer adapter | Installation of output shaft taper roller bearing outer race |
|  | MB990931 | Installer adapter | Installation of cap |
|  | MB990935 | Installer adapter | Installation of differential taper roller bearing outer race <F4A42> |
|  | MB990936 | Installer adapter | Installation of differential taper roller bearing outer race <F4A51> Installation of output shaft taper roller bearing <F4A41, F4A42> |
|  | MB990937 | Installer adapter | Installation of output shaft taper roller bearing <F4A51> |
|  | MB990938 | Handle | <ul style="list-style-type: none"> • Installation of input shaft rear bearing • Use with installer adapter |
|  | MB991625 | Special socket (41) | Removal and installation of output shaft lock nut |

| Tool | Number | Name | Use |
|---|----------|-----------------------|--|
|  | MB991626 | Socket (60) | Removal and installation of transfer drive gear lock nut <F4A41, F4A42> |
|  | MB991628 | Spring compressor | <ul style="list-style-type: none"> Removal and installation of low-reverse brake snap ring <F4A41, F4A42> Measurement of underdrive clutch and overdrive clutch end plays <F4A41, F4A42> |
|  | MB991629 | Spring compressor | Measurement of underdrive clutch and overdrive clutch end plays <F4A51> |
|  | MB991631 | Clearance dummy plate | Measurement of low-reverse brake and second brake end plays <F4A41, F4A42> |
|  | MB991632 | Clearance dummy plate | Measurement of low-reverse brake and second brake end plays <F4A51> |
|  | MB991789 | Spring compressor | Measurement of reverse clutch end play <F4A51> |
|  | MB991790 | Spring compressor | Measurement of reverse clutch end play <F4A41, F4A42> |
|  | MD998333 | Oil pump remover | Removal of oil pump |
|  | MD998334 | Oil seal installer | Installation of oil pump oil seal |

| Tool | Number | Name | Use |
|---|----------|-------------------------|---|
|  | MD998338 | Spring compressor | Removal and installation of low-reverse brake snap ring <F4A51> |
|  | MD998348 | Bearing and gear puller | Removal of transfer drive gear bearing |
|  | MD998350 | Bearing installer | Installation of output shaft, collar, bearing |
|  | MD998412 | Guide | Installation of oil pump and transfer drive gear |
|  | MD998800 | Oil seal installer | Installation of drive shaft oil seal |
|  | MD998801 | Bearing remover | Removal of each bearing |
|  | MD998812 | Installer cap | Use with installer and installer adapter. |
|  | MD998813 | Installer – 100 | Use with installer cap and installer adapter. |
|  | MD998814 | Installer – 200 | Use with installer cap and installer adapter. |


| Tool | Number | Name | Use |
|--|----------|---------------------------|--|
| A cylindrical metal adapter with a central hole and a slightly wider outer rim. | MD998819 | Installer adapter (40) | Installation of differential ball bearing <F4A41> |
| A cylindrical metal adapter with a central hole and a slightly wider outer rim, similar to MD998819 but with a different internal profile. | MD998820 | Installer adapter (42) | Installation of differential taper roller bearing <F4A42> |
| A cylindrical metal adapter with a central hole and a slightly wider outer rim, similar to MD998819 but with a different internal profile. | MD998823 | Installer adapter (48) | Installation of output shaft taper roller bearing <F4A41, F4A42>, transfer drive gear <F4A41, F4A42> |
| A cylindrical metal adapter with a central hole and a slightly wider outer rim, similar to MD998819 but with a different internal profile. | MD998824 | Installer adapter (50) | Installation of transfer drive gear <F4A51>, differential taper roller bearing <F4A51> |
| A cylindrical metal adapter with a central hole and a slightly wider outer rim, similar to MD998819 but with a different internal profile. | MD998827 | Installer adapter (56) | Installation of output shaft taper roller bearing <F4A51> |
| A cylindrical metal adapter with a central hole and a slightly wider outer rim, similar to MD998819 but with a different internal profile. | MD998829 | Installer adapter (60) | Installation of transfer drive gear bearing <F4A41, F4A42> |
| A metal tool with a T-shaped cross-section and a central hole, used for compressing springs. | MD998903 | Spring compressor | Removal and installation of one-way clutch inner race snap ring <F4A42> |
| A metal tool with a C-shaped cross-section and a central hole, used for compressing springs. | MD998907 | Spring compressor | Removal and installation of underdrive clutch snap ring |
| A long, thin metal rod with a slightly wider end, used as an extension for a dial gauge. | MD998913 | Dial gauge extension | Measurement of low-reverse brake and second brake end plays |

| Tool | Number | Name | Use |
|---|----------|----------------------------|--|
|  | MD998917 | Bearing remover | Removal of output shaft taper roller bearing |
|  | MD998924 | Spring compressor retainer | <ul style="list-style-type: none"> ● Removal and installation of low-reverse brake snap ring ● Measurement of underdrive clutch and overdrive clutch end plays |
|  | MD999590 | Spring compressor | Removal and installation of overdrive clutch snap ring |

3. TRANSMISSION

DISASSEMBLY AND REASSEMBLY <F4A41 up to Dec. 1997, F4A42-1 up to Dec. 1997 and F4A42-2 without one-way clutch>


Apply automatic transmission fluid to all moving parts before installation.



TFA1996

- 1. Torque converter
- 2. Roll stopper bracket
- 3. Harness bracket
- 4. Control cable support bracket
- 5. Oil level gauge
- 6. Eye bolt
- 7. Oil cooler feed tube
- 8. Oil filter
- 9. Oil filter gasket

- 10. Input shaft speed sensor
- 11. Output shaft speed sensor
- 12. Manual control lever
- 13. Inhibitor switch
- 14. Speedometer gear
- 15. Valve body cover
- 16. Manual control shaft detent spring
<Model 1996 only>
- 17. Manual control shaft detent




TFA1587

- 18. Fluid temperature sensor
- 19. Valve body
- 20. Steel ball
- 21. Gasket
- 22. Snap ring
- 23. Solenoid valve harness
- 24. Strainer

- 25. Second brake retainer oil seal
- 26. Accumulator piston
- 27. Accumulator spring
- 28. Accumulator spring
- 29. Manual control lever shaft roller
- 30. Manual control lever shaft
- 31. Parking pawl rod

Apply automatic transmission fluid to all moving parts before installation.




- 32. Torque converter housing
- 33. Differential <F4A41>
- 34. Spacer <F4A41>
- 35. Spacer <F4A41-1-MRA only>
- 36. Differential <F4A42>
- 37. Oil filter
- 38. Oil pump

- 39. Gasket
- 40. Thrust washer #1
- 41. Underdrive clutch and input shaft
- 42. Thrust bearing #2
- 43. Underdrive clutch hub
- 44. Outer race <F4A42>
- 45. Spacer <F4A42>

No. of Brake Discs and Plates

| Brake | Model | Brake Disc | Brake Plate |
|----------------------|--------------------|------------|-------------|
| Low-reverse brake | F4A41 | 4 | 3 |
| | F4A42-1 | 5 | 4 |
| | F4A42-2 | 6 | 5 |
| Second brake | F4A41 | 2 | 1 |
| | F4A42-1 F4A42-2 | 3 | 2 |




TFA1979

46. Rear cover
47. Thrust race #8
48. Seal ring
49. Input shaft rear bearing
50. Thrust bearing #7
51. Reverse and overdrive clutch
52. Thrust bearing #6
53. Overdrive clutch hub
54. Thrust bearing #5
55. Planetary reverse sun gear
56. Snap ring
57. Second brake piston
58. Return spring
59. Pressure plate
60. Second brake disc
61. Second brake plate
62. Overdrive planetary carrier
63. Thrust bearing #4
64. Output planetary carrier
65. Underdrive sun gear
66. Thrust bearing #3
67. Snap ring
68. Reaction plate
69. Snap ring
70. Low-reverse brake disc
71. Low-reverse brake plate
72. Pressure plate
73. Wave spring
74. Parking pawl shaft
75. Spacer
76. Parking pawl spring
77. Parking roller support shaft
78. Parking pawl
79. Parking roller support
80. Snap ring
81. Spring retainer
82. Return spring
83. Low-reverse brake piston
84. Transfer drive gear
85. Cap
86. Lock nut
87. Output shaft
88. Taper roller bearing
89. Collar
90. Outer race
91. Spacer
92. Snap ring
93. Outer race
94. Transmission case

DISASSEMBLY AND REASSEMBLY <F4A41 from Jan. 1998 and F4A42-1 from Jan. 1998>


Apply automatic transmission fluid to all moving parts before installation.



TFA2268

- 1. Torque converter
- 2. Roll stopper bracket
- 3. Harness bracket
- 4. Control cable support bracket
- 5. Oil level gauge
- 6. Eye bolt
- 7. Oil cooler feed tube
- 8. Oil filter

- 9. Oil filter gasket
- 10. Input shaft speed sensor
- 11. Output shaft speed sensor
- 12. Manual control lever
- 13. Inhibitor switch
- 14. Speedometer gear
- 15. Valve body cover
- 16. Manual control shaft detent




TFA1587

- 17. Fluid temperature sensor
- 18. Valve body
- 19. Steel ball
- 20. Gasket
- 21. Snap ring
- 22. Solenoid valve harness
- 23. Strainer

- 24. Second brake retainer oil seal
- 25. Accumulator piston
- 26. Accumulator spring
- 27. Accumulator spring
- 28. Manual control lever shaft roller
- 29. Manual control lever shaft
- 30. Parking pawl rod

Apply automatic transmission fluid to all moving parts before installation.




TFA2256

- 31. Torque converter housing
- 32. Differential <F4A41>
- 33. Spacer <F4A41>
- 34. Differential <F4A42-1>
- 35. Oil filter
- 36. Oil pump
- 37. Gasket

- 38. Thrust washer #1
- 39. Underdrive clutch and input shaft
- 40. Thrust bearing #2
- 41. Underdrive clutch hub
- 42. Outer race <F4A42-1>
- 43. Spacer <F4A42-1>

No. of Brake Discs and Plates

| Brake | Model | Brake Disc | Brake Plate |
|-------------------|---------|------------|-------------|
| Low-reverse brake | F4A41 | 4 | 3 |
| | F4A42-1 | 5 | 4 |
| Second brake | F4A41 | 2 | 1 |
| | F4A42-1 | 3 | 2 |




TFA2257

44. Rear cover
45. Thrust race #8
46. Seal ring
47. Input shaft rear bearing
48. Thrust bearing #7
49. Reverse and overdrive clutch
50. Thrust bearing #6
51. Overdrive clutch hub
52. Thrust bearing #5
53. Planetary reverse sun gear
54. Snap ring
55. Second brake piston
56. Return spring
57. Pressure plate
58. Second brake disc
59. Second brake plate
60. Overdrive planetary carrier
61. Thrust bearing #4
62. Output planetary carrier
63. Underdrive sun gear
64. Thrust bearing #3
65. Snap ring
66. Reaction plate
67. Snap ring
68. Low-reverse brake disc
69. Low-reverse brake plate
70. Pressure plate
71. Wave spring
72. Parking pawl shaft
73. Spacer
74. Parking pawl spring
75. Parking roller support shaft
76. Parking pawl
77. Parking roller support
78. Snap ring
79. Spring retainer
80. Return spring
81. Low-reverse brake piston
82. Transfer drive gear
83. Cap
84. Lock nut
85. Output shaft
86. Taper roller bearing
87. Collar
88. Outer race
89. Spacer
90. Snap ring
91. Outer race
92. Transmission case

DISASSEMBLY AND REASSEMBLY <F4A42-2 with one-way clutch>


Apply automatic transmission fluid to all moving parts before installation.



TFA2268

- 1. Torque converter
- 2. Roll stopper bracket
- 3. Harness bracket
- 4. Control cable support bracket
- 5. Oil level gauge
- 6. Eye bolt
- 7. Oil cooler feed tube
- 8. Oil filter

- 9. Oil filter gasket
- 10. Input shaft speed sensor
- 11. Output shaft speed sensor
- 12. Manual control lever
- 13. Inhibitor switch
- 14. Speedometer gear
- 15. Valve body cover
- 16. Manual control shaft detent




TFA1587

- 17. Fluid temperature sensor
- 18. Valve body
- 19. Steel ball
- 20. Gasket
- 21. Snap ring
- 22. Solenoid valve harness
- 23. Strainer


- 24. Second brake retainer oil seal
- 25. Accumulator piston
- 26. Accumulator spring
- 27. Accumulator spring
- 28. Manual control lever shaft roller
- 29. Manual control lever shaft
- 30. Parking pawl rod

Apply automatic transmission fluid to all moving parts before installation.



TFA2046

- | | |
|------------------------------|---------------------------------------|
| 31. Torque converter housing | 37. Underdrive clutch and input shaft |
| 32. Differential | 38. Thrust bearing #2 |
| 33. Oil filter | 39. Underdrive clutch hub |
| 34. Oil pump | 40. Outer race |
| 35. Gasket | 41. Spacer |
| 36. Thrust washer #1 | |




TFA2048

- 42. Rear cover
- 43. Thrust race #8
- 44. Seal ring
- 45. Input shaft rear bearing
- 46. Thrust bearing #7
- 47. Reverse and overdrive clutch
- 48. Thrust bearing #6
- 49. Overdrive clutch hub
- 50. Thrust bearing #5
- 51. Planetary reverse sun gear
- 52. Snap ring
- 53. Second brake piston
- 54. Return spring
- 55. Pressure plate
- 56. Second brake disc
- 57. Second brake plate
- 58. Planetary carrier assembly
- 59. Snap ring
- 60. Reaction plate
- 61. Snap ring
- 62. Low-reverse brake disc
- 63. Low-reverse brake plate
- 64. Pressure plate
- 65. Wave spring

- 66. Parking pawl shaft
- 67. Spacer
- 68. Parking pawl spring
- 69. Parking roller support shaft
- 70. Parking pawl
- 71. Parking roller support
- 72. Snap ring
- 73. One-way clutch inner race
- 74. O-ring
- 75. Spring retainer
- 76. Return spring
- 77. Low-reverse brake piston
- 78. Transfer drive gear
- 79. Cap
- 80. Lock nut
- 81. Output shaft
- 82. Taper roller bearing
- 83. Collar
- 84. Outer race
- 85. Spacer
- 86. Snap ring
- 87. Outer race
- 88. Transmission case

DISASSEMBLY AND REASSEMBLY <F4A51>


Apply automatic transmission fluid to all moving parts before installation.



TFA1980

- 1. Torque converter
- 2. Roll stopper bracket
- 3. Harness bracket
- 4. Control cable support bracket
- 5. Oil level gauge
- 6. Oil filter
- 7. Oil filter gasket


- 8. Input shaft speed sensor
- 9. Output shaft speed sensor
- 10. Manual control lever
- 11. Inhibitor switch
- 12. Speedometer gear
- 13. Valve body cover
- 14. Manual control shaft detent



- 15. Fluid temperature sensor
- 16. Valve body
- 17. Steel ball
- 18. Gasket
- 19. Snap ring
- 20. Solenoid valve harness
- 21. Strainer

- 22. Second brake retainer oil seal
- 23. Accumulator piston
- 24. Accumulator spring
- 25. Accumulator spring
- 26. Manual control lever shaft roller
- 27. Manual control lever shaft
- 28. Parking pawl rod


Apply automatic transmission fluid to all moving parts before installation.



TFA2234

- 29. Torque converter housing
- 30. Differential
- 31. Oil filter
- 32. Oil pump
- 33. Gasket
- 34. Thrust washer #1

- 35. Underdrive clutch and input shaft
- 36. Thrust bearing #2
- 37. Underdrive clutch hub
- 38. Outer race
- 39. Spacer



TFA2235

- 40. Rear cover
- 41. Thrust race #8
- 42. Seal ring
- 43. Input shaft rear bearing
- 44. Thrust bearing #7
- 45. Rear and overdrive clutch
- 46. Thrust bearing #6
- 47. Overdrive clutch hub
- 48. Thrust bearing #5
- 49. Planetary reverse sun gear
- 50. Snap ring
- 51. Second brake piston
- 52. Return spring
- 53. Pressure plate
- 54. Second brake disc
- 55. Second brake plate
- 56. Planetary carrier assembly
- 57. Snap ring
- 58. Reaction plate
- 59. Snap ring
- 60. Low-reverse brake disc
- 61. Low-reverse brake plate
- 62. Pressure plate
- 63. Wave spring


- 64. Parking pawl shaft
- 65. Spacer
- 66. Parking pawl spring
- 67. Parking roller support shaft
- 68. Parking pawl
- 69. Parking roller support
- 70. Snap ring
- 71. One-way clutch inner race
- 72. O-ring
- 73. Spring retainer
- 74. Return spring
- 75. Low-reverse brake piston
- 76. Transfer drive gear
- 77. Cap
- 78. Lock nut
- 79. Output shaft
- 80. Taper roller bearing
- 81. Collar
- 82. Outer race
- 83. Spacer
- 84. Snap ring
- 85. Outer race
- 86. Transmission case

Intentionally blank


DISASSEMBLY

Caution


1. Because the automatic transmission is manufactured from high-precision parts, sufficient care must be taken not to scratch or damage these parts during disassembly and reassembly.
2. The working area should be covered with a rubber mat to keep it clean at all times.
3. Do not wear any cloth gloves and do not use any rags during disassembly. Use nylon cloth or paper towels if you need to use something.
4. Parts which have been disassembled should all be cleaned. Metal parts can be cleaned with normal detergent, but they should be dried completely using compressed air.
5. Clutch discs, plastic thrust plates and rubber parts should be cleaned with automatic transmission fluid (ATF) so that they do not become dirty.
6. If the transmission body has been damaged, disassemble and clean the cooler system also.



- (1) Remove the torque converter.
- (2) Use the dial gauge to measure the input shaft end play.
- (3) Remove each bracket.
- (4) Remove the oil level gauge.
- (5) Remove the eye bolt, gasket and the oil cooler feed tube.
- (6) Remove the oil filter.




- (7) Remove the input shaft speed sensor and output shaft speed sensor.




- (8) Remove the manual control lever, and then remove the inhibitor switch.

Caution


Make sure that the valve body is installed before removing the manual control lever installation nut.




(9) Remove the speedometer gear.




(10) Remove the valve body cover.




(11) Remove the manual control shaft detent spring and the manual control shaft detent. <Model 1996>



Remove the manual control shaft detent. <from Model 1997>




(12) Disconnect the harness connectors of the valve body.



- (13) Remove the valve body mounting bolts (28 pieces).
- (14) Remove the fluid temperature sensor.

Caution


Make sure that the manual control lever and the inhibitor switch are removed.




- (15) Remove the valve body, gasket and the steel balls (2 pieces).

Caution


Do not lose the steel balls (2 pieces).



- (16) Remove the snap ring, and then remove the solenoid valve harness.




- (17) Remove the strainer and the second brake retainer oil seal.




- (18) Remove each accumulator piston and spring.


| No. | Name |
|-----|-----------------------|
| 1 | For low-reverse brake |
| 2 | For underdrive clutch |
| 3 | For second brake |
| 4 | For overdrive clutch |




- (19) Remove the manual control lever shaft roller.
- (20) Remove the manual control lever shaft and the parking pawl rod.




- (21) Remove the torque converter housing mounting bolts (18 pieces), and then remove the torque converter housing.




- (22) Remove the O-rings (2 pieces).




- (23) Remove the differential and the spacer(s) (3 pieces F4A41-1-MRA only). <F4A41>




- (24) Remove the differential. <F4A42, F4A51>




(25) Remove the oil filter.




(26) Remove the oil pump mounting bolts (6 pieces).
(27) Install the special tool (MD998333) in the hole A.




(28) Screw the special tool to remove the oil pump.
(29) Remove the oil pump gasket.




(30) Remove the thrust washer #1.




(31) Hold the input shaft, and then remove the underdrive clutch.



(32) Remove the thrust bearing #2.



(33) Remove the underdrive clutch hub.




(34) Remove the rear cover.


(35) Remove the thrust race #8.

(36) Remove the seal rings (4 pieces).


(37) Remove the input shaft rear bearing.




(38) Remove the O-rings (3 pieces).




(39) Remove the reverse and overdrive clutch and the thrust bearing #7.




(40) Remove the overdrive clutch hub and the thrust bearing #6.




(41) Remove the thrust bearing #5.




(42) Remove the planetary reverse sun gear.



(43) Remove the snap ring.




(44) Remove the second brake piston and the return spring.




(45) Remove the pressure plate, brake discs and brake plate(s).

No. of brake discs and plates


| Model | Brake disc | Brake plate | Pressure plate |
|-------|------------|-------------|----------------|
| F4A41 | 2 | 1 | 1 |
| F4A42 | 3 | 2 | 1 |
| F4A51 | 4 | 3 | 1 |




(46) Remove the overdrive planetary carrier <F4A41, F4A42-1 and F4A42-2 without one-way clutch> or planetary carrier assembly <F4A42-2 with one-way clutch and F4A51>.




(47) Remove the output planetary carrier and the thrust bearing #4. <F4A41, F4A42-1 and F4A42-2 without one-way clutch>




(48) Remove the underdrive sun gear and the thrust bearing #3 from the output planetary carrier. <F4A41, F4A42-1 and F4A42-2 without one-way clutch>




(49) Remove the snap ring.



(50) Remove the reaction plate and the brake disc.




(51) Remove the snap ring.




(52) Remove the brake plates, brake discs and pressure plate.

No. of brake discs and plates


| Model | Brake disc | Brake plate | Pressure plate |
|----------------|------------|-------------|----------------|
| F4A41 | 4 | 3 | 1 |
| F4A42-1 | 5 | 4 | 1 |
| F4A42-2, F4A51 | 6 | 5 | 1 |




(53) Remove the wave spring.






(54) Remove the parking pawl shaft, and then remove the spacer and spring.




(55) Remove the two parking roller support shafts, and then remove the parking pawl case and parking roller support.





(56) Use the special tool to remove the snap ring.
 (57) Remove the one-way clutch inner race <F4A42-2 with one-way clutch and F4A51>, O-ring <F4A42-2 with one-way clutch and F4A51>, spring retainer, return spring and the low-reverse brake piston.




(58) Remove the transfer drive gear bearing mounting bolts as follows:
 F4A41, F4A42-1 and F4A42-2 without one-way clutch:
 Remove all 4 mounting bolts.
 F4A42-2 with one-way clutch: First remove 4 or 3 bolts, then turn the gear $\frac{1}{8}$ turn (45°) and remove the remaining 3 or 4 bolts (7 bolts in total).
 F4A51: First remove 4 bolts, then turn the gear $\frac{1}{8}$ turn (45°) and remove the remaining 4 bolts (8 bolts in total).




(59) Remove the transfer drive gear.



(60) Remove the cap.




(61) Straighten the locking tab of the output shaft lock nut.




(62) Use the special tool to remove the output shaft lock nut.


Caution
The lock nut is a left-handed screw.



(63) Remove the bearing retainer mounting bolt.



(64) Tap on the rear of the output shaft to remove the output shaft, taper roller bearing and the collar.



(65) Remove the spacer and the outer race.
 (66) Remove the snap ring.

(67) Remove the differential bearing outer race and spacer from the torque converter housing. <F4A42, F4A51>


(68) Remove the differential bearing outer race from the transmission case. <F4A42, F4A51>

Intentionally blank

REASSEMBLY


Caution

1. Never reuse the gasket, O-ring, oil seal, etc. Always replace with a new one when reassembling.
2. Never use grease other than blue petrolatum jelly and white Vaseline.
3. Apply ATF to friction components, rotating parts, and sliding parts before installation. Immerse a new clutch disc or brake disc in ATF for at least two hours before assembling them.
4. Never apply sealant or adhesive to gaskets.
5. When replacing a bushing, replace the assembly which it belongs to.
6. Never use any cloth gloves or any rags during reassembly. Use nylon cloth or paper towels if you need to use something.
7. Change the oil in the cooler system.




- (1) Use the special tools to tap the differential bearing outer race in the transmission case. <F4A42, F4A51>


| Model | Special tools No. |
|-------|--------------------|
| F4A42 | MB990935, MB990938 |
| F4A51 | MB990936, MB990938 |



- (2) Use the special tools to tap the output shaft bearing outer race in the transmission case.
- (3) Install the used spacer and snap ring.



- (4) Use the special tool to install the transfer drive gear. <F4A41 from Jan. 1998, F4A42-1 from Jan. 1998, F4A42-2 with one-way clutch and F4A51>




(4a) Tighten the mounting bolts of the transfer drive gear bearing to the specified torque. <F4A41 from Jan. 1998, F4A42-1 from Jan. 1998, F4A42-2 with one-way clutch and F4A51>

F4A41 and F4A42-1 = 4 mounting bolts


F4A42-2 with one-way clutch = 7 mounting bolts

F4A51 = 8 mounting bolts





(5) Install the low-reverse brake piston, return spring and spring retainer.

(5a) Check the placement of the identification notches in the one-way clutch inner race. Install the one-way clutch inner race with O-ring to the transfer drive gear bearing so that the notches fall along the A – A line. <F4A42-2 with one-way clutch and F4A51>





(5b) Use the special tools to install the snap ring.





(6) Install the wave spring.



(7) Install the brake disc, brake plate and special tool and snap ring as shown in the figure.

Caution


If necessary, take the measurements in steps 9 to 18 after replacing the pressure plate, brake plate and brake disc.

NOTE

Do not install the pressure plate at this time.

Number of brake discs and plates


| Model | Brake disc | Brake plate | Special tool |
|----------------|------------|-------------|--------------|
| F4A41 | 4 | 3 | 1 |
| F4A42-1 | 5 | 4 | 1 |
| F4A42-2, F4A51 | 6 | 5 | 1 |






(8) Install the reaction plate and the used snap ring.

(9) Move the special tool to measure the end play, and then replace the snap ring installed in step (8) to adjust the end play to standard value.

Standard value: 0 – 0.16 mm










(10) Install the brake disc, brake plate and special tool MB991631 <F4A41, F4A42> or MB991632 <F4A51> as shown in the figure.

Number of brake discs and plates

| Model | Brake disc | Brake plate |
|-------|------------|-------------|
| F4A41 | 2 | 1 |
| F4A42 | 3 | 2 |
| F4A51 | 4 | 3 |

(11) Install the return spring, second brake piston and snap ring.






(12) Move the special tool and measure its movement.
 Select a pressure plate whose thickness corresponds to the measured amount of movement from the following table.


Standard value of end play (Reference):






- 0.49 – 0.95 mm <F4A41>
- 0.79 – 1.25 mm <F4A42>
- 1.09 – 1.55 mm <F4A51>



Pressure plate for F4A41 and F4A42

| Movement amount mm | | Thickness mm | ID symbol | Part No. |
|--------------------|-----------|--------------|-----------|----------|
| F4A41 | F4A42 | | | |
| 0.3 – 0.5 | 0.6 – 0.8 | 1.6 | L | MD759567 |
| 0.5 – 0.7 | 0.8 – 1.0 | 1.8 | 1 | MD759414 |
| 0.7 – 0.9 | 1.0 – 1.2 | 2.0 | 0 | MD759415 |
| 0.9 – 1.1 | 1.2 – 1.4 | 2.2 | 2 | MD759416 |
| 1.1 – 1.3 | 1.4 – 1.6 | 2.4 | 4 | MD759417 |
| 1.3 – 1.5 | 1.6 – 1.8 | 2.6 | 6 | MD759418 |





Pressure plate for F4A51

| Movement amount mm | Thickness mm | ID symbol | Part No. |
|--------------------|--------------|-----------|----------|
| 1.1 – 1.3 | 1.8 | E | MD759425 |
| 1.3 – 1.5 | 2.0 | D | MD759426 |
| 1.5 – 1.7 | 2.2 | C | MD759427 |
| 1.7 – 1.9 | 2.4 | B | MD759428 |
| 1.9 – 2.1 | 2.6 | A | MD759429 |
| 2.1 – 2.3 | 2.8 | 0 | MD759430 |

(13) Reverse the transmission.

(14) Install the special tool (MD998913) in a dial gauge, and then move the special tool (MB991631 or MB991632) and measure its movement.






Select a pressure plate whose thickness corresponds to the measured amount of movement from the following table.

Standard value of end play (Reference):

1.05 – 1.51 mm <F4A41>

1.35 – 1.81 mm <F4A42-1>

1.65 – 2.11 mm <F4A42-2 and F4A51>




Pressure plate for F4A41 and F4A42

| Movement amount mm | | | Thick- ness mm | ID symbol | Part No. |
|--------------------|-----------|-----------|----------------------|--------------|----------|
| F4A41 | F4A42-1 | F4A42-2 | | | |
| 0.7 – 0.9 | 1.0 – 1.2 | 1.3 – 1.5 | 1.6 | L | MD759567 |
| 0.9 – 1.1 | 1.2 – 1.4 | 1.5 – 1.7 | 1.8 | 1 | MD759414 |
| 1.1 – 1.3 | 1.4 – 1.6 | 1.7 – 1.9 | 2.0 | 0 | MD759415 |
| 1.3 – 1.5 | 1.6 – 1.8 | 1.9 – 2.1 | 2.2 | 2 | MD759416 |
| 1.5 – 1.7 | 1.8 – 2.0 | 2.1 – 2.3 | 2.4 | 4 | MD759417 |
| 1.7 – 1.9 | 2.0 – 2.2 | 2.3 – 2.5 | 2.6 | 6 | MD759418 |
| 1.9 – 2.1 | 2.2 – 2.4 | 2.5 – 2.7 | 2.8 | 8 | MD759419 |
| 2.1 – 2.3 | 2.4 – 2.6 | 2.7 – 2.9 | 3.0 | D | MD759420 |


Pressure plate for F4A51

| Movement amount mm | Thickness mm | ID symbol | Part No. |
|--------------------|-----------------|-----------|----------|
| 1.0 – 1.2 | 1.6 | F | MD759568 |
| 1.2 – 1.4 | 1.8 | E | MD759425 |
| 1.4 – 1.6 | 2.0 | D | MD759426 |
| 1.6 – 1.8 | 2.2 | C | MD759427 |
| 1.8 – 2.0 | 2.4 | B | MD759428 |
| 2.0 – 2.2 | 2.6 | A | MD759429 |
| 2.2 – 2.4 | 2.8 | 0 | MD759430 |
| 2.4 – 2.6 | 3.0 | 1 | MD759431 |

- (15) Remove the parts installed from steps (6) to (14).
- (16) Install the output shaft in the transmission case and tighten the mounting bolts of the output shaft bearing retainer to the specified torque.




(17) Use the special tool to install the collar and taper roller bearing in the output shaft.



(18) Apply ATF to a new lock nut, and use the special tool to tighten the lock nut to the specified torque. Then turn back one turn, and tighten to the specified torque again.


Caution

The lock nut is a left-hand screw.




(19) Move the output shaft to measure operating amount (A), and then replace the spacer installed in step (3) with a new one which thickness is within the following value.


[A (operating amount) + B (thickness of the old spacer) + 0.01 mm] to [A (operating amount) + B (thickness of the old spacer) + 0.09 mm]




(20) Stake the lock nut with a punch (two places).




(21) Install the cap as shown in the figure.




(22) Use the special tool to install the transfer drive gear.
 <F4A41 up to Dec. 1997, F4A42-1 up to Dec. 1997 and F4A42-2 without one-way clutch>




(23) Tighten the four mounting bolts of the transfer drive gear to the specified torque.
 <F4A41 up to Dec. 1997, F4A42-1 up to Dec. 1997 and F4A42-2 without one-way clutch>



(24) Install the parking pawl, spacer, and spring. Then install the parking pawl shaft.




(25) Install the parking roller support, and then the two parking roller support shafts.



(26) Install the underdrive sun gear and thrust bearing #3 to the output planetary carrier.
 <F4A41, F4A42-1 and F4A42-2 without one-way clutch>

Caution
 Be careful about the installation direction of the thrust bearing.


<F4A41, F4A42>



IDENTIFICATION OF THRUST BEARINGS, THRUST RACES, AND THRUST WASHERS


mm

| Sym- bol | O.D. | I.D. | Thick- ness | Part number | Sym- bol | O.D. | I.D. | Thick- ness | Part number |
|-------------|------|------|----------------|-------------|-------------|------|------|----------------|-------------|
| #1 | 59 | 47 | 1.8 | MD754509 | #8 | 48.9 | 37 | 1.6 | MD707267 |
| | | | 2.0 | MD754508 | | | | 1.7 | MD759681 |
| | | | 2.2 | MD754507 | | | | 1.8 | MD723064 |
| | | | 2.4 | MD753793 | | | | 1.9 | MD754794 |
| | | | 2.6 | MD753794 | | | | 2.0 | MD707268 |
| | | | 2.8 | MD753795 | | | | 2.1 | MD754795 |
| #2 | 49 | 36 | 3.6 | MD756846 | | | | 2.2 | MD723065 |
| #3 | 49 | 36 | 3.6 | MD756846 | | | | 2.3 | MD754796 |
| #4 | 45.3 | 31 | 3.3 | MD757647 | | | | 2.4 | MD724358 |
| #5 | 49 | 36 | 3.6 | MD756846 | | | | 2.5 | MD754797 |
| #6 | 49 | 36 | 3.6 | MD756846 | | | | 2.6 | MD754798 |
| #7 | 59 | 37 | 2.8 | MD754595 | | | | | |




(27) Install the output planetary carrier and thrust bearing #4. <F4A41, F4A42-1 and F4A42-2 without one-way clutch>


Caution
Be careful about the installation direction of the thrust bearing.




(28) Install the overdrive planetary carrier <F4A41, F4A42-1 and F4A42-2 without one-way clutch> or planetary carrier assembly <F4A42-2 with one-way clutch and F4A51>.



(29) Install the planetary reverse sun gear.




(30) Install the wave spring.




(31) Install the pressure plate, brake disc, and brake plate.

Number of brake discs and plates


| Model | Brake disc | Brake plate | Pressure plate |
|----------------|------------|-------------|----------------|
| F4A41 | 4 | 3 | 1 |
| F4A42-1 | 5 | 4 | 1 |
| F4A42-2, F4A51 | 6 | 5 | 1 |




(32) Install the snap ring.




(33) Install the reaction plate.




(34) Install the snap ring.




(35) Install the brake disc, brake plate, and pressure plate.



(36) Install the return spring and second brake piston.




(37) Install the snap ring.



(38) Install the thrust bearing #5.

Caution


Be careful about the installation direction of the thrust bearing.



(39) Install the overdrive clutch hub and thrust bearing #6 to the reverse and overdrive clutch.

Caution


Be careful about the installation direction of the thrust bearing




(40) Install the reverse and overdrive clutch, and thrust bearing #7.

Caution


Be careful about the installation direction of the thrust bearing



(41) Install the three O-rings.



- (42) Use special tool and tap the input shaft bearing in the rear cover.
- (43) Install the four seal rings in the grooves of the rear cover.



- (44) Install the thinnest thrust race #8 (thickness 1.6 mm: part No. MD707267) on thrust bearing #7, then install the rear cover and tighten the bolts to the specified torque.
- (45) Measure end play of the underdrive sun gear and record the measurement value.


NOTE

Installing the underdrive clutch hub makes it easy to measure the end play of the underdrive sun gear.

Standard value: 0.25 – 0.45 mm

Select a thrust race #8 whose thickness corresponds to the measured value from the table below, and replace the thrust race installed in step (44) with the selected one.


| Measurement value mm | Thickness mm | Part No. |
|----------------------|--------------|----------|
| 0.3 – 0.4 | 1.6 | MD707267 |
| 0.4 – 0.5 | 1.7 | MD759681 |
| 0.5 – 0.6 | 1.8 | MD723064 |
| 0.6 – 0.7 | 1.9 | MD754794 |
| 0.7 – 0.8 | 2.0 | MD707268 |
| 0.8 – 0.9 | 2.1 | MD754795 |
| 0.9 – 1.0 | 2.2 | MD723065 |
| 1.0 – 1.1 | 2.3 | MD754796 |
| 1.1 – 1.2 | 2.4 | MD724358 |
| 1.2 – 1.3 | 2.5 | MD754797 |
| 1.3 – 1.4 | 2.6 | MD754798 |




- (46) Squeeze out the liquid gasket of 1.6 mm in diameter and apply it to the shown points of the rear cover.

Liquid gasket:


MITSUBISHI genuine sealant Part No. MD974421 or equivalent



(47) Install the rear cover, and tighten its mounting bolts to the specified torque.




(48) Install the underdrive clutch hub.




(49) Install the thrust bearing #2.

Caution
Install the thrust bearing in correct direction.




(50) Hold the input shaft, and install the underdrive clutch.



(50a) Place two beads of solder [each 10 mm in length, 3.5 mm in diameter] on the underdrive clutch retainer as shown in the illustration.

23A-3-27a AUTOMATIC TRANSMISSION (E-W) – Transmission




- (50b) Install special tool in the illustrated place.
 (50c) Install the oil pump to the transaxle case.


NOTE

Do not install the oil pump gasket at this time.

- (50d) Tighten the oil pump mounting bolts (6 pieces) to the specified torque.




- (50e) Remove the oil pump mounting bolts.
 (50f) Using special tool, remove the oil pump, and then take out the crushed solders.




- (50g) Use a micrometer to measure the thickness of the crushed solder beads and record the measured value.
 (50h) Select a thrust washer # 1 whose thickness corresponds to the measured value from table below.

| Measurement value mm | Thickness mm | ID symbol | Part No. |
|----------------------|--------------|-----------|----------|
| 2.25 – 2.45 | 1.8 | 18 | MD754509 |
| 2.45 – 2.65 | 2.0 | 20 | MD754508 |
| 2.65 – 2.85 | 2.2 | 22 | MD754507 |
| 2.85 – 3.05 | 2.4 | 24 | MD753793 |
| 3.05 – 3.25 | 2.6 | 26 | MD753794 |
| 3.25 – 3.45 | 2.8 | 28 | MD753795 |



- (51) Install the used thrust washer #1 that was selected in step (50h) on the underdrive clutch retainer.

Intentionally blank




(52) Use the special tool to install a new oil pump gasket and oil pump.

Caution


Never reuse the old gasket.

(53) Tighten the oil pump mounting bolts to the specified torque.




(54) Make sure that the input shaft end play meets the standard value.

Standard value: 0.70 – 1.45 mm




(55) Install the oil filter.




<F4A41>

(56) Install the spacer (F4A41-1-MRA only), and then the differential. <F4A41>




<F4A42, F4A51>


(57) Install the differential. <F4A42, F4A51>




- (58) Install the 1.25-mm-thick spacer. <F4A41-1-MRA only>
 (59) Place a solder (approx. 10 mm in length, 3 mm in diameter) on the differential as shown in the figure. <F4A41>



- (60) Place a solder (approx. 10 mm in length, 3 mm in diameter) on the torque converter housing as shown in the figure. <F4A42, F4A51>



- (61) Install the torque converter housing to the transmission case without applying sealant. Tighten its mounting bolts to the specified torque.
 (62) Loosen the bolts, and remove the solder.




- (63) Use a micrometer to measure the thickness (T) of the pressed solder. Select a spacer which thickness is within the following value.

F4A41


(T - 0.045 mm) to (T - 0.165 mm)

F4A42, F4A51

(T + 0.045 mm) to (T + 0.105 mm)




- (64) Install the spacer selected in the above step. <F4A41>




(65) Assemble the spacer selected in step (63) to the torque converter housing. Use the special tools to press in the outer race.

| Model | Special tools No. |
|--------------|--------------------|
| F4A41, F4A42 | MB990935, MB990938 |
| F4A51 | MB990936, MB990938 |




(66) Squeeze out the liquid gasket of 1.6 mm in diameter and apply it to the shown points of torque converter.


Liquid gasket:
MITSUBISHI genuine sealant Part No. MD974421
or equivalent



(67) Install the two O-rings.




(68) Install the torque converter, and then tighten its 18 mounting bolts to the specified torque.



(69) Install the manual control lever shaft and parking pawl rod.

(70) Install the manual control lever shaft roller.




(71) Install the accumulator pistons, new seal rings, and springs.


NOTE

The accumulator springs are identified as shown in the figure.


| No. | Name |
|-----|-----------------------|
| 1 | For low-reverse brake |
| 2 | For underdrive clutch |
| 3 | For second brake |
| 4 | For overdrive clutch |




(72) Install the strainer and second brake retainer oil seal.




(73) Install the solenoid valve harness, and then secure the snap ring to the connector groove.




(74) Install the valve body, gasket, and two steel balls.






- (75) Install the fluid temperature sensor.
- (76) Install the 28 mounting bolts of the valve body.




- (77) Connect the connectors of the valve body.


| No. | Parts to be connected | Cable colour | Connector housing colour |
|-----|--------------------------------------|----------------------|--------------------------|
| 1 | Underdrive solenoid valve | White, red, red | Black |
| 2 | Overdrive solenoid valve | Orange, red | Black |
| 3 | Low-reverse solenoid valve | Brown, yellow | Milky white |
| 4 | Second solenoid valve | Green, red, red | Milky white |
| 5 | Damper clutch control solenoid valve | Blue, yellow, yellow | Black |
| 6 | Fluid temperature sensor | Black, red | Black |



- (78) Install the manual control shaft detent spring and detent. <Model 1996>




- Install the manual control shaft detent. <Model 1997>




(79) Apply the liquid gasket to the valve body cover.


Liquid gasket:
MITSUBISHI genuine sealant Part No. MD974421
or equivalent




(80) Install the valve body cover, and then tighten its mounting bolts to the specified torque.




(81) Install the speedometer gear.



(82) Install the inhibitor switch and manual control lever.



(83) Install the input shaft speed sensor and output shaft speed sensor.




(84) Apply a small amount of ATF to the oil filter gasket. Tighten the filter to the specified torque.

(85) Install the eye bolt, a new gasket, and the oil cooler feed tube.

(86) Install the oil dipstick.

(87) Install the brackets.



(88) Install the torque converter, and secure it so that the shown dimension (A) meets the reference value.

Reference value: approx. 12.2 mm <F4A41, F4A42>
approx. 9.4 mm <F4A51>


Caution

Apply ATF to the oil pump drive hub before installing the torque converter. Be careful not to damage the oil seal lip when installing the torque converter.

4. OIL PUMP

DISASSEMBLY AND REASSEMBLY

Apply automatic transmission fluid to all moving parts before installation.




TFA2204

Disassembly steps

- ▶B◀ 1. O-ring
- 2. Seal ring
- ▶A◀ 3. Oil seal
- 4. Oil pump assembly

REASSEMBLY SERVICE POINTS

▶A◀ OIL SEAL INSTALLATION




▶B◀ O-RING INSTALLATION

Install a new O-ring to the outer groove of the oil pump, and apply ATF to the O-ring.

5. UNDERDRIVE CLUTCH AND INPUT SHAFT

DISASSEMBLY AND REASSEMBLY



TFA1564

Number of clutch discs and plates


| Model | Clutch disc | Clutch plate | Clutch reaction plate |
|-----------------|-------------|--------------|-----------------------|
| F4A41 | 3 | 3 | 1 |
| F4A42, F4A51 | 4 | 4 | 1 |

Disassembly steps

- 1. Snap ring
- 2. Input shaft
- 3. Seal ring
- ▶D◀ 4. Snap ring
- ▶C◀ 5. Clutch reaction plate
- ▶C◀ 6. Clutch disc
- ▶C◀ 7. Clutch plate
- ▶A◀ ▶B◀ 8. Snap ring

- ▶A◀ 9. Spring retainer
- ▶A◀ 10. D-ring
- ▶A◀ 11. Return spring
- ▶A◀ 12. Underdrive clutch piston
- ▶A◀ 13. D-ring
- ▶A◀ 14. D-ring
- ▶A◀ 15. Underdrive clutch retainer

23A-5-2 AUTOMATIC TRANSMISSION (E-W) – Underdrive Clutch and Input Shaft




DISASSEMBLY SERVICE POINTS

◀A▶ SNAP RING REMOVAL

REASSEMBLY SERVICE POINTS

▶A◀ D-RING INSTALLATION

Apply ATF, blue petrolatum jelly or white Vaseline to D-ring, and install carefully.




▶B◀ SNAP RING INSTALLATION

▶C◀ CLUTCH PLATE/CLUTCH DISC/CLUTCH REACTION PLATE INSTALLATION

(1) Align each teeth missing part (part A) of the clutch plate, clutch disc and clutch reaction plate to the outer circumference hole (part B) of the underdrive clutch retainer.

Caution


Immerse the clutch disc in ATF before assembling it.




(2) Install the clutch reaction plate in the shown direction.

Number of clutch discs and plates

| Model | Clutch disc | Clutch plate | Clutch reaction plate |
|-----------------|-------------|--------------|-----------------------|
| F4A41 | 3 | 3 | 1 |
| F4A42, F4A51 | 4 | 4 | 1 |





▶D◀ SNAP RING INSTALLATION

Check that the clearance between the snap ring and the clutch reaction plate is within the standard value. When measuring the clearance, use the special tool to press the clutch reaction plate evenly. If not within the standard value, select a snap ring to adjust.

Standard value:

1.2 – 1.4 mm <F4A41>


1.6 – 1.8 mm <F4A42, F4A51>

| Model | Special tools No. |
|--------------|--------------------|
| F4A41, F4A42 | MB991628, MD998924 |
| F4A51 | MB991629, MD998924 |

6. REVERSE AND OVERDRIVE CLUTCH

DISASSEMBLY AND REASSEMBLY

Apply automatic transmission fluid to all moving parts before installation.



TFA2208

Number of clutch discs and plates


| | Model | Pressure plate | Clutch disc | Clutch plate | Clutch reaction plate |
|-------------------|-------|----------------|-------------|--------------|-----------------------|
| Over-drive clutch | F4A41 | – | 3 | 3 | 1 |
| | F4A42 | – | 4 | 4 | 1 |
| | F4A51 | 1 | 4 | 3 | 1 |
| Reverse clutch | | – | 2 | 2 | 1 |

Disassembly steps

- ▶G▶ 1. Snap ring
- ▶F▶ 2. Clutch reaction plate
- ▶F▶ 3. Clutch disc
- ▶F▶ 4. Clutch plate
- ▶E▶ 5. Snap ring
- ▶D▶ 6. Clutch reaction plate
- ▶D▶ 7. Clutch disc
- ▶D▶ 8. Clutch plate
- ▶D▶ 9. Pressure plate <F4A51>
- ▶A▶▶C▶ 10. Snap ring
- ▶A▶▶C▶ 11. Spring retainer

- ▶A▶▶ 12. D-ring
- ▶A▶▶ 13. Return spring
- ▶A▶▶ 14. Overdrive clutch piston
- ▶A▶▶ 15. D-ring
- ▶B▶▶ 16. Reverse clutch piston
- ▶A▶▶ 17. D-ring
- ▶A▶▶ 18. Reverse clutch retainer
- ▶A▶▶ 19. D-ring
- ▶A▶▶ 20. D-ring

23A-6-2 AUTOMATIC TRANSMISSION (E-W) – Reverse and Overdrive Clutch




DISASSEMBLY SERVICE POINT

◀▶ SNAP RING REMOVAL

REASSEMBLY SERVICE POINTS


▶◀ D-RING INSTALLATION

Apply ATF, blue petrolatum jelly or white Vaseline to D-ring, and install carefully.



▶◀ REVERSE CLUTCH PISTON INSTALLATION


Align the outer circumference holes (parts A and B) of the reverse clutch piston and the reverse clutch retainer to assemble them.



▶◀ SNAP RING INSTALLATION

- (1) Set special tools as shown in the illustration.
- (2) Tighten the nut on the special tool to press down on the spring retainer and reverse clutch retainer, and then install the snap ring.
- (3) Check that the clearance between the snap ring and the return spring retainer is within the standard value. If not within the standard value, select a snap ring to adjust.

Standard value: 0–0.09 mm






▶◀ PRESSURE PLATE / CLUTCH PLATE / CLUTCH DISC / CLUTCH REACTION PLATE INSTALLATION

Install the clutch reaction plate in the shown direction.

Caution

Immerse the clutch disc in ATF before assembling the clutch disc.



▶E◀ SNAP RING INSTALLATION


Check that the clearance between the snap ring and the clutch reaction plate is within the standard value. When measuring the clearance, use the special tool to press the clutch reaction plate evenly. If not within the standard value, select a snap ring to adjust.

Standard value:

1.2 – 1.4 mm <F4A41>

1.6 – 1.8 mm <F4A42, F4A51>

| Model | Special tools No. |
|--------------|--------------------|
| F4A41, F4A42 | MB991628, MD998924 |
| F4A51 | MB991629, MD998924 |




▶F◀ CLUTCH PLATE / CLUTCH DISC / CLUTCH REACTION PLATE INSTALLATION

- (1) Align each teeth missing part (part A) of the clutch plate, clutch disc and clutch reaction plate to the outer circumference hole (part B) of the reverse clutch retainer.


Caution

Immerse the clutch disc in ATF.

23A-6-4 AUTOMATIC TRANSMISSION (E-W) – Reverse and Overdrive Clutch



- (2) Install the clutch reaction plate in the shown direction.




▶G◀ SNAP RING INSTALLATION


- (1) Install the snap ring into the groove of reverse clutch retainer.
- (2) Set special tools MB991790 <F4A4> or MB991789 <F4A5> and MD998924 as shown in the illustration, and compress the clutch element.
- (3) Check that the clearance between the snap ring and the clutch reaction plate is within the standard value. If not within the standard value, select a snap ring to adjust.

Standard value: 1.5 – 1.7 mm

7. OVERDRIVE PLANETARY CARRIER <F4A41, F4A42 without ONE-WAY CLUTCH>

DISASSEMBLY AND REASSEMBLY

 Apply automatic transmission fluid to all moving parts before installation.



TFA2258


Disassembly steps

1. Snap ring
2. Overdrive planetary carrier
3. Overdrive annulus gear

7a.PLANETARY CARRIER ASSEMBLY <F4A42 with ONE-WAY CLUTCH, F4A51>

DISASSEMBLY AND REASSEMBLY

Apply automatic transmission fluid to all moving parts before installation.




TFA2042

Disassembly steps

- ▶B◀ 1. Stopper plate
- ▶B◀ 2. One-way clutch
- ▶B◀ 3. Snap ring
- ▶A◀ 4. Output planetary carrier
- ▶A◀ 5. Thrust bearing #3

- ▶A◀ 6. Underdrive sun gear
- ▶A◀ 7. Thrust bearing #4
- ▶A◀ 8. Snap ring
- ▶A◀ 9. Overdrive planetary carrier
- ▶A◀ 10. Overdrive annulus gear



TFA2043

REASSEMBLY SERVICE POINTS

▶A◀ THRUST BEARING #3 / THRUST BEARING #4 INSTALLATION


Check the installation direction of thrust bearings number 3 and 4, and install them as shown.

Caution

Be careful about the installation direction of the thrust bearings.


▶B◀ ONE-WAY CLUTCH INSTALLATION


Insert the one-way clutch into the overdrive annulus gear so that the arrow points to the output planetary carrier side.



8. LOW-REVERSE BRAKE
DISASSEMBLY AND REASSEMBLY

23300370047

 Lubricate all internal parts with automatic transmission fluid during reassembly.



TFA1373

Disassembly steps



1. D-ring
2. D-ring
3. Low-reverse brake piston

REASSEMBLY SERVICE POINT


▶A◀ D-RING INSTALLATION


Apply ATF, blue petrolatum jelly or white Vaseline to D-ring, and install carefully.

9. SECOND BRAKE

23302180013

DISASSEMBLY AND REASSEMBLY

 Lubricate all internal parts with automatic transmission fluid during reassembly.



TFA1374

Disassembly steps

- ▶A◀ 1. Second brake retainer
- 2. D-ring
- 3. Second brake piston
- ▶A◀ 4. D-ring


REASSEMBLY SERVICE POINT


▶A◀ **D-RING INSTALLATION**

Apply ATF, blue petrolatum jelly or white Vaseline to D-ring, and install carefully.

10. OUTPUT SHAFT

DISASSEMBLY AND REASSEMBLY


 Lubricate all internal parts with automatic transmission fluid during reassembly.



TFA1375


Disassembly steps

- ◀A▶ ▶C▶ 1. Transfer driven gear
- ▶B▶ ▶A▶ 2. Bearing retainer
- ▶B▶ ▶A▶ 3. Outer race
- ▶B▶ ▶A▶ 4. Taper roller bearing
- ▶B▶ ▶A▶ 5. Output shaft




DISASSEMBLY SERVICE POINTS

- ◀A▶ TRANSFER DRIVEN GEAR REMOVAL




◀B▶ TAPER ROLLER BEARING REMOVAL



REASSEMBLY SERVICE POINTS


▶A◀ TAPER ROLLER BEARING INSTALLATION

| Model | Special tools No. |
|--------------|------------------------------|
| F4A41, F4A42 | MD998812, MD998814, MD998823 |
| F4A51 | MD998812, MD998814, MD998827 |



▶B◀ OUTER RACE INSTALLATION

| Model | Special tools No. |
|--------------|--------------------|
| F4A41, F4A42 | MB990936, MB990938 |
| F4A51 | MB990937, MB990938 |





▶C◀ TRANSFER DRIVEN GEAR INSTALLATION

| Model | Special tools No. |
|--------------|------------------------------|
| F4A41, F4A42 | MD998812, MD998813, MB998823 |
| F4A51 | MD998812, MD998813, MB998824 |

11. TRANSFER DRIVE GEAR <F4A41 up to Dec. 1997, F4A42 up to Dec. 1997>

DISASSEMBLY AND REASSEMBLY

 Apply automatic transmission fluid to all moving parts before installation.




TFA1376

Disassembly steps

- 

 1. Lock nut


 2. Transfer drive gear bearing
 3. Transfer drive gear




TFA1539


DISASSEMBLY SERVICE POINTS

◀A▶ LOCK NUT REMOVAL


- (1) Pull up the turning stopper of the lock nut.



(2) Use the special tool to remove the lock nut.




◀B▶ TRANSFER DRIVE GEAR BEARING REMOVAL




REASSEMBLY SERVICE POINTS

▶A▶ TRANSFER DRIVE GEAR BEARING INSTALLATION



▶B▶ LOCK NUT INSTALLATION

(1) Apply ATF to a new lock nut, and tighten it to the specified torque. Then turn back one turn, and tighten to the specified torque again.




(2) Use a punch or other to prevent the nut from turning (two points).

12. DIFFERENTIAL

DISASSEMBLY AND REASSEMBLY

Apply automatic transmission fluid to all moving parts before installation.




TFA1556

Disassembly steps


- ◀A▶ ▶E▶ 1. Differential drive gear
- ◀B▶ ▶D▶ 2. Ball bearings <F4A41>
- ▶C▶ 3. Taper roller bearings <F4A42, F4A51>
- ▶B▶ 4. Lock pin
- ▶A▶ 5. Pinion shaft

- ▶A▶ 6. Pinions
- ▶A▶ 7. Washers
- ▶A▶ 8. Side gears
- ▶A▶ 9. Spacers
- 10. Differential case




DISASSEMBLY SERVICE POINTS

◀A▶ BALL BEARING REMOVAL



◀B▶ TAPER ROLLER BEARING REMOVAL



REASSEMBLY SERVICE POINTS



▶A◀ SPACER, SIDE GEAR, WASHER, PINION, PINION SHAFT INSTALLATION

- (1) Install the spacers to the back side of the side gears, and then assemble the side gears into the differential case.

NOTE

Select the medium size spacer (0.93 – 1.00 mm) when assembling a new side gear.


- (2) Attach the washers to the back side of the pinions, engage the pinions simultaneously to the side gears, and settle the gears by turning.
- (3) Insert the pinion shaft.



- (4) Measure the backlash between the side gears and pinions.
Standard value: 0.025 – 0.150 mm
- (5) If not within the standard value, change a spacer and measure the backlash again.


NOTE

Adjust so that both backlashes are equal.




▶B◀ LOCK PIN INSTALLATION

Install the lock pin in the shown direction.




▶C◀ TAPER ROLLER BEARING INSTALLATION

| Model | Special tools No. |
|-------|--------------------|
| F4A42 | MD998812, MD998820 |
| F4A51 | MD998812, MD998824 |





▶D◀ BALL BEARING INSTALLATION



▶E◀ DIFFERENTIAL DRIVE GEAR INSTALLATION


Apply ATF to the bolt, tighten the bolts to the specified torque in the shown sequence.



13. VALVE BODY

DISASSEMBLY AND REASSEMBLY

Lubricate all internal parts with automatic transmission fluid during reassembly.





TFA1378

Disassembly steps

- 1. Solenoid valve support
- 2. Underdrive solenoid valve
- 3. Second solenoid valve
- 4. Damper clutch control solenoid valve
- 5. Overdrive solenoid valve
- 6. Low-reverse solenoid valve
- 7. Manual valve
- 8. Cover
- 9. Plate
- 10. Outside valve body assembly

- 11. Steel ball (orifice check ball)
- 12. Spring
- 13. Plate
- 14. Damping valve
- 15. Damping valve spring
- 16. Steel ball (line relief)
- 17. Spring
- 18. Steel ball (orifice check ball)
- 19. Spring
- 20. Inside valve body assembly


 Lubricate all internal parts with automatic transmission fluid during reassembly.




TFA1589

- 21. Roller
- 22. Damper clutch control valve sleeve
- 23. Damper clutch control valve
- 24. Damper clutch control valve spring
- 25. Plate
- 26. Screw
- 27. Regulator valve spring
- 28. Regulator valve
- 29. Plate
- 30. Fail-safe valve A sleeve
- 31. Fail-safe valve A2

- 32. Fail-safe valve A spring
- 33. Fail-safe valve A1
- 34. Plate
- 35. Plug
- 36. Torque converter valve
- 37. Torque converter valve spring
- 38. Plate
- 39. Fail-safe valve B sleeve
- 40. Fail-safe valve B
- 41. Inside valve body

 Lubricate all internal parts with automatic transmission fluid during reassembly.



TFA1590

- | | |
|---|---|
| <ul style="list-style-type: none"> 42. Roller 43. Overdrive pressure control valve sleeve 44. Overdrive pressure control valve 45. Overdrive pressure control valve spring 46. Roller 47. Low-reverse pressure control valve sleeve 48. Low-reverse pressure control valve 49. Low-reverse pressure control valve spring 50. Plate 51. Plug | <ul style="list-style-type: none"> 52. Switching valve 53. Roller 54. Underdrive pressure control valve sleeve 55. Underdrive pressure control valve 56. Underdrive pressure control valve spring 57. Roller 58. Second pressure control valve sleeve 59. Second pressure control valve 60. Second pressure control valve spring 61. Outside valve body |
|---|---|


DISASSEMBLY SERVICE POINT

◀A▶ SOLENOID VALVES REMOVAL


Mark solenoid valves by white paint to make reassembly easier.

REASSEMBLY SERVICE POINTS

▶A◀ SPRING/STEEL BALL/DAMPING VALVE/DAMPING VALVE SPRING INSTALLATION




▶B◀ SPRING/STEEL BALL INSTALLATION




▶C◀ SOLENOID VALVES INSTALLATION





- (1) Apply ATF, blue petrolatum jelly or white Vaseline to O-ring, and install carefully.
- (2) Install the solenoid valves by referring to the marks during disassembly.



| No. | Name |
|-----|--------------------------------------|
| 1 | Underdrive solenoid valve |
| 2 | Second solenoid valve |
| 3 | Damper clutch control solenoid valve |
| 4 | Overdrive solenoid valve |
| 5 | Low–reverse solenoid valve |

14. SPEEDOMETER GEAR DISASSEMBLY AND REASSEMBLY

 Apply automatic transmission fluid to all moving parts before installation.




TFM0593


Disassembly steps

1. e-clip
2. Speedometer driven gear
3. O-ring
4. Sleeve

15. DRIVE SHAFT OIL SEAL

DISASSEMBLY AND REASSEMBLY

 Lubricate all internal parts with automatic transmission fluid during reassembly.




TFA1380

Disassembly steps

- ▶A◀ 1. Oil seal
- 2. Torque converter housing
- ▶B◀ 3. Oil seal
- 4. Transmission case

REASSEMBLY SERVICE POINT

▶A◀ OIL SEAL INSTALLATION



23A-15-2 AUTOMATIC TRANSMISSION (E-W) – Drive Shaft Oil Seal

▶B◀ OIL SEAL INSTALLATION

